## CUCCIO PRO LUMEN X

# CUCCIO<sup>™</sup> product portfolio

#### DESCRIPTION

The new LumenX a Rechargeable LED curing lamp For Manicures & Pedicures.

## FEATURES AND BENEFITS

- Complete 5 finger lamp
- · Deep in bulbs design protect hand while curing
- Two-sided bulbs for best curing of thumb
- White Case Design to maximize the power of wavelength
- High quality PC Plastic Case
- ·Rechargeable lamp.
- ·Cures all our LED and the UV gel.
- Have a shut down mechanism to prevent the battery to drain or make it last longer

## **DIRECTION FOR USE**

**Operation Instructions:** 

1. Turn on the switch of the lamp.

2.Automatic sensor mode: when the hand is placed into the lamp, thenail lamp will begin to work. When the hand is removed, the lamp stopsworking. Select the desired curing time, see chart below. Manual mode: press the time you need, set the button for the 10S/30S/60S (normal mode) countdown to work, the lamp will shut off when the time is complete. If you need to stop working halfway, press the time key to stop.

3. There are 2 additional timer buttons as follows: 3 x 60 LOW power forgels or people that are sensitive or to avoid hot spikes during curing. Pushthe 3x60 Low power and the lamp will start out at thirty percent of thepower, after 30 seconds increase another 30% and finally reaching the fullcuring power for a slower cure. 90S High Power should be used for highlypigmented gels such as black and white or sculpting with gel when you dothicker applications.





Item-CCPL4000

4.Intelligent double power output. Press the 60S button, the countdownto work. The lamp is not designed to dry nail polish, use the lamp for anyLED product.5.The lamp can also be used for curing toes by removing the bottom trayand placing the lamp over the toes. Be

sure to place the lamp directly overthe toes and cure according to the chart listed below.

6. When the lamp is not in use for 10 minutes the lamp automatically sleeps and goes into a state of power protection. The display stops showing thetime and will wake up by pressing the 90 second key when it is used again.

MGARCIA@CUCCIO.COM